

BOEING 767

PASSENGER WINDOWS

PART NUMBER CROSS REFERENCE LIST

BOEING PART NUMBERS			GKN ATS / PMA Part Numbers		
ASSEMBLY					
	LWA	CrystalVue	A352S LWA	CrystalVue	CrystalVue with Edge Seal
140T2411	140T2421	140T2421	PA140T2421	PA140T2421	PA140T2421
-1	-1	-601	-1	-601	-601S
-2	-2	-602	-2	-602	-602S
-3	-3	-603	-3	-603	-603S
-4	-4	-604	-4	-604	-604S
-5	-5/-7	-605	-5	-605	-605S
<i>Alternate Part Numbers</i>	<i>140U4006-215</i>	<i>140U4006-615</i>	<i>SI140U4006-15</i>	<i>PA140U4006-615</i>	<i>PA140U4006-615S</i>
OUTER PANES					
	LWA	CrystalVue	A352S LWA	CrystalVue	CrystalVue with Edge Seal
140T2413	140T2423	140T2423	PA140T2423	PA140T2423	PA140T2423
-1	-1	-601	-1	-1AR or -601	-1AS or 601S
-2	-2	-602	-2	-2AR or -602	-2AS or 602S
-3	-3	-603	-3	-3AR or -603	-3AS or 603S
-4	-4	-604	-4	-4AR or -604	-4AS or 604S
-5	-5'	-605'	-5'	-5AR or -605'	-5AS or 605S'
<i>Alternate Part Numbers</i>	<i>140U4005-15</i>	<i>140U4005-615</i>	<i>SI140U4005-15</i>	<i>PA140U4005-15AR</i> <i>PA140U4005-615</i>	<i>PA140U4005-15AS</i> <i>PA140U4005-615S</i>

BOEING 767 PASSENGER WINDOWS

PART NUMBER CROSS REFERENCE LIST

Boeing Part Numbers		GKN ATS / PMA Part Numbers	
MIDDLE PANES	LWA	A352 LWA	A352S LWA
140T2415	140T2415	SI140T2415	SI140T2415
-1	-1	-301	-501
-2	-2	-302	-502
-3	-3	-303	-503
-4	-4	-304	-504
-5	-5, -9	-305, -9	-505, -9
-7	-7	-307	-507
-8	-8	-308	-508
SEALS			
	65B07671		PA65B07671
	-5		-5
	-6		-6
	-7		-7
	-8		-8
	-9		-9
	-10		-10



12122 Western Ave.
Garden Grove, CA 92841
Tel.: 714.893.7531
Fax: 714.892.7635
SITA SNAPAXD

Eckersall Road, Kings Norton
Birmingham, B38 8SR England
Tel.: 44.121.606.4100
Fax: 44.121.606.4191
ARINC: BHPXZXD

9/21 Moo 5, Phaholyothin Road
Klong 1, Klong Luang,
Patumthanee, Thailand 12120
Tel.: 66.2.516.1058
Fax: 66.2.902.0414

Avenida Central, 211 - Chácaras
Reunidas, CEP 12238-430
São José dos Campos, SP-Brazil
Tel.: 55.012.3934.3418
Fax: 55.012.3931.9006

London Luton Airport
Luton Bedfordshire
LU2 9PQ, United Kingdom
Tel.: +44 (0) 1582.731441
Fax: + 44 (0) 1582.452049